


DIRECTION OF ROTATION - TYRE FITTING GUIDE



X = Specification Number – Located on one sidewall of each tyre